

## 1. General Description

This Document contains the log data of a read out logfile. It shows what happened with the specified vbar unit during the latest time

Version of PC Software	<b>5.3.2b 31.12.2012</b>
Date	<b>Sun Sep 18 18:01:25 EEST 2016</b>
Serial	<b>1410042375</b>
Prod Date	<b>23.5.2014 9:23</b>
Firmware	<b>5.3</b>
Patchlevel	<b>4</b>

## 2. Chronological List of Events

▶	0:16	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	0:25	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	0:35	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	0:44	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	0:54	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:04	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:13	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:23	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:33	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:42	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:51	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	2:01	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	2:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:21	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:31	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:41	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:51	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:01	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:21	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:31	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:41	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:51	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.

✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	0:34	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	0:35	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	0:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	3:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds

▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:05	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
▶	0:15	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	0:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.



✔	9:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	10:25	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	10:25	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	0:32	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	0:34	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	0:44	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:54	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:04	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:14	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:24	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:34	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:44	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:54	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.





✔	6:44	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:54	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:04	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:14	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:24	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:34	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:44	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:54	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:04	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:14	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:16	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	8:17	Testmode Ended	Testmode has been switched off intentially. Normal control loop is in action now
✔	8:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:44	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	8:45	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	8:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	10:26	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.



✓	15:07	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	15:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	15:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	15:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	15:47	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	15:57	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	16:07	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	16:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	16:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	16:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	16:47	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	16:57	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	17:07	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	17:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✓	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✓	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	0:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	0:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	1:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	1:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	1:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	1:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	1:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	2:40	Governor ON	Governor switched to mode ON
✔	2:50	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	2:53	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	3:03	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:13	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:22	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	3:32	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	3:42	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:52	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:54	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	4:00	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	4:10	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:20	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:30	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:40	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:50	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:00	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:10	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:20	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:30	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:40	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	5:46	Governor ON	Governor switched to mode ON
▶	5:55	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	6:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	6:41	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
✔	6:51	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:01	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:21	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:31	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:41	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:51	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	8:01	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:10	Governor ON	Governor switched to mode ON
▶	8:20	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	8:30	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:33	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	8:39	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	8:49	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:59	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:09	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:19	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:29	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:39	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:49	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:59	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:09	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	10:10	Governor ON	Governor switched to mode ON
✔	10:20	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	10:25	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	10:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	10:42	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
✔	10:52	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	10:54	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	11:04	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	11:14	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	11:24	Testmode Started	The testmode is entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	11:25	Testmode Started	The testmode is entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	11:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	11:4 5	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	11:5 5	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	12:0 5	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	12:1 4	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	12:1 5	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
✔	12:2 5	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	12:3 5	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	12:4 4	Governor ON	Governor switched to mode ON
✔	12:5 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:0 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:1 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	13:1 8	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	13:2 8	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:3 8	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:4 8	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	13:5 6	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	14:0 6	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	14:1 6	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	14:2 5	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	14:3 5	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	14:3 9	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
⚠	14:4 4	High Vibration Level	The control loop suffers from a high vibration level, that starts to render the sensors blind. Save flying is possible, but the stability will be degraded. Additinally slow drifts that happen may be caused by vibrations.
✔	14:5 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:0 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:1 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:2 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	15:3 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:4 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:5 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	16:0 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	16:1 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	16:2 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	16:3 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	16:4 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	16:5 0	Governor ON	Governor switched to mode ON
✔	17:0 0	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	17:1 0	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	17:1 8	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	17:2 8	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	17:3 8	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	17:4 8	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	17:5 0	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	17:5 7	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	18:0 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	18:1 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	18:2 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	18:3 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	18:4 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered by manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory



✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	0:43	Governor ON	Governor switched to mode ON
✔	0:53	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	0:57	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	1:07	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	1:16	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	1:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	2:43	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	2:53	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:02	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	3:12	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
▶	3:17	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	3:21	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	3:31	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:41	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:51	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:01	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	4:11	Governor ON	Governor switched to mode ON



✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
⚠	0:01	Init Failed, retrying...	The Init process of the sensors is very sensitive to movements of the heli or from other external disturbances, i.e. Voltage jumps and glitches. This can lead to a failed initialization. In this Case it is repeated. If this repeats itself all the time, this can point to a defective sensors.
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	1:36	Governor ON	Governor switched to mode ON
✔	1:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	1:50	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
✔	2:00	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:10	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:20	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:30	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	2:35	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	2:36	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	2:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.

▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
⚠	0:01	Init Failed, retrying...	The Init process of the sensors is very sensitive to movements of the heli or from other external disturbances, i.e. Voltage jumps and glitches. This can lead to a failed initialization. In this Case it is repeated. If this repeats itself all the time, this can point to a defective sensors.
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	1:10	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	1:11	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	1:14	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	1:15	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	1:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:02	Governor Mode Throttlecurve	Governor off, the servo moves with the programmed internal throttle curve
✔	3:12	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:22	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:31	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.

▶	3:32	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
✔	3:42	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:48	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	3:49	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	3:50	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	4:00	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:10	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
⚠	4:16	Governor Full Throttle	The Governour is not able to hold the Headspeed, but there is no more throttle available. Check the maximum collective and the power of your engine. This message is issued only if there is a massive demand on more energy.
▶	4:19	Governor Mode Throttlecurve	Governor off, the servo moves with the programmed internal throttle curve
✔	4:29	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:39	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:49	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:59	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	5:08	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	5:08	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
✔	5:18	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	5:28	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	5:29	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	5:33	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	5:43	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	5:51	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
✔	6:01	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:21	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:31	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:41	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

▶	6:45	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	6:47	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	6:57	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	7:07	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
✔	7:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	7:27	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	7:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:47	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	7:54	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
▶	8:01	Governor ON	Governor switched to mode ON
✔	8:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:21	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:23	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
✔	8:33	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:43	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:53	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	9:03	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	9:04	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	9:12	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	9:17	Testmode Ended	Testmode has been switched off intentionally. Normal control loop is in action now
✔	9:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:47	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:57	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:07	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	10:47	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:57	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
⚠	0:02	Init Failed, retrying...	The Init process of the sensors is very sensitive to movements of the heli or from other external disturbances, i.e. Voltage jumps and glitches. This can lead to a failed initialization. In this Case it is repeated. If this repeats itself all the time, this can point to a defective sensors.
▶	0:07	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
▶	0:13	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	0:15	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
✔	0:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.





✓	8:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	8:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	8:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	8:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	8:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	8:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	9:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	9:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	9:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	9:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	9:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	9:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	10:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	10:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	10:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	10:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	10:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	10:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	11:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	11:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✗	11:24	RC Input of Channel 2 out of Range	Channel 2 actively received a Signal that is out of the specified Signal range of 0.8ms .. 2.2ms. These Signals are ignored, but point to a serious problem with the configuration. Make sure you never leave the valid signal range of the inputs. Invalid inputs will trigger the missing signal error as well, because there is no usable signal anymore. This has to be done in this way, because bad connections tend to create invalid signals because of glitches.
✓	11:34	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	11:44	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	11:54	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	12:04	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	12:14	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✓	12:24	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	12:3 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	12:4 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	12:5 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:0 4	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	13:0 6	Testmode Started	The testmode ist entered intentionally by the user with the command on a Controlpanel or any other control terminal. The Entering command is checksum tested, so it cannot happen accidentally. In Testmode the normal control loop algorithm is not running, so its important to leave the Testmode prior flight. Its only can happen to fly in testmode with bluetooth.
▶	13:0 7	Testmode Ended	Testmode has been switched off intentially. Normal control loop is in action now
✔	13:1 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:2 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:3 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:4 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	13:5 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	14:0 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	14:1 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	14:2 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	14:3 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	14:4 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	14:5 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:0 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:1 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:2 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	15:3 7	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	2:48	Governor ON	Governor switched to mode ON
▶	2:54	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	2:58	Governor ON	Governor switched to mode ON
▶	2:58	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	2:59	Governor ON	Governor switched to mode ON
✔	3:09	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	3:12	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	3:22	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:32	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:42	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:52	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	4:00	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	4:10	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	4:20	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:30	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	4:40	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	4:50	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	4:58	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	5:07	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	5:17	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	5:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	5:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	5:47	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
✘	5:55	Extreme Vibration Level	Vibrations are extreme. That means, that the measurement signal is much lower than the signal level of the vibrations. No usable flying is possible with this level. Everything has to be checked and extended tests are needed to isolate and eliminate the source of vibrations
✔	6:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	7:08	Governor ON	Governor switched to mode ON
✔	7:18	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	7:22	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	7:32	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	7:41	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	7:51	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:01	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:20	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	8:29	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.

✔	8:39	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	8:49	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	8:51	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	8:58	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	9:08	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:18	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:28	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:38	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:48	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	9:58	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:08	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:11	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:21	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	10:31	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered by manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:05	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	1:10	Governor ON	Governor switched to mode ON
▶	1:16	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	1:26	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.



▶	4:58	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	5:07	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	5:17	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	5:27	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
▶	5:36	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and this is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeatedly very often, check the heli for vibration sources.
✔	5:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
▶	5:52	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
⚠	5:55	High Vibration Level	The control loop suffers from a high vibration level, that starts to render the sensors blind. Save flying is possible, but the stability will be degraded. Additionally slow drifts that happen may be caused by vibrations.
✔	6:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	6:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	7:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered by manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:00	Governor Mode Stop	Governor switched to mode Stop, Servo to minimum
▶	0:07	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.